ZIPPY-SCAFF 2.9M EXTENSION PACK ALUMINIUM



ASSEMBLY INSTRUCTIONS

GURAD RAIL PACK 2.9M EXTENSION SCAFFOLDING PACK COMPONENTS - ITEM CODE - AL-FSXP29		
Item Code	Description	QTY
AL-FSLF	Frame-Ladder-1.0m	2
AL-FSBRAD	Diagonal Brace	2
AL-FSBRAH	Horizontal Brace	1
AL-OUT2030	Outrigger Assy, 2.0-3.0m Adj	2
A-LAD27A	Ladder w/Brace Arms 2.7m	1
AL-FSTB21	Folding Toeboard Assembly	1

GENERAL

These assembly instructions apply to assembly of the base unit with guard rail pack 1.9m and 2.9m configuration of the Oldfields Zippy-Scaff folding scaffold, where the deck height is greater than 1.2m above ground level up to a maximum of 2.9m.

The base unit & 1.9m guard rail pack needs to be assembled first before components for the 2.9m guard rail pack can be added. With base unit and 1.9m guard rail pack already assembled, follow these steps:

Step 1: Attach outriggers to vertical legs of Base Frames and adjust accordingly to ensure the foots makes firm contact with the ground. Tighten all wing nuts on outriggers.

Step 2: Fit plain deck platform between each third rung of Base Frames (approx. 0.9m above castor level).

Step 3: Fit one diagonal brace between opposing Base Frames.

Step 4: Fit 1.0m extension frames to top of Base Frames.

Step 5: Fit the remaining two diagonal braces between opposing extension frames.

Step 6: Fit the hatch deck platform between the top rung of the extension frames.

Step 7: Fit guardrail frames to top of the extension frames.

Step 8: From the working platform attach the Handrail assembly between Guardrail frames on one side of the tower and attach the two horizontal braces on the opposite side. Ensure brace hooks face outwards.

Note: Access to the working platform is gained by climbing up rungs through the hatch opening, from inside the tower. Fit Toe board Kit if required.

The Zippy-Scaff Base Unit with 2.9m Guard Rail Pack configuration is now ready to use.

Note: Deck Maximum Working Load is 225kgs

ZIPPY-SCAFF 2.9M EXTENSION PACK ALUMINIUM



ASSEMBLY INSTRUCTIONS

ACCESS TO ZIPPY-SCAFF WITH 2.9M GUARD RAIL PACK

Access to the working platform is gained by climbing up rungs through the hatch opening, from inside the tower. **DO NOT CLIMB UP THE OUTSIDE OF THE ZIPPY-SCAFF.**

TO DISMANTLE ZIPPY-SCAFF WITH 2.9M GUARD RAIL PACK

Follow the assembly instructions going backwards through the steps.

CAUTIONS & NOTES:

Keep fingers clear of pinch points. Recommended safe work practices when using the oldfields **Zippy-Scaff Folding Scaffold** include, but are not limited to the following:

- Zippy-Scaff Folding Scaffold must not be used as a working platform, alongside stair voids or at the edge of mezzanine floors, on balconies, unprotected slab edge, penetration or step down, under any circumstances.
- **Zippy-Scaff Folding Scaffold** must be used on a hard, flat, level surface.
- Avoid power lines (minimum clearance 4m...Consult your local electricity supply authority).
- Keep Zippy-Scaff Folding Scaffold platform and surrounding work area clear of material and debris.
- Inspect your **Zippy-Scaff Folding Scaffold** for damage prior to use. Do not use if damaged. Consult Oldfields for scaffold repairs.
- When moving **Zippy-Scaff Folding Scaffold**, keep a firm hold of frames unless unit is fully opened and castors are locked.
- Wear and use appropriate personal protective equipment for the job being done.
- Keep fingers (and other body parts) clear of potential pinch points (e.g. ends of braces, under platform hooks, etc.) whilst opening or closing Zippy-Scaff Folding Scaffold.

- Do not exert significant sideward force (pushing / pulling) at right angles to the platform (unless it is tied to a secure structure).
- Do not exert excessive pulling force parallel to the platform (unless it is tied to a secure structure).
- Castors should be locked at all times unless
 Zippy-Scaff Folding Scaffold is being relocated.
- **Zippy-Scaff Folding Scaffold** must not be relocated while any person or objects are on the platform.
- Do not attach banners, signs or containment sheeting to Zippy-Scaff Folding Scaffold unless it is tied to a secure structure.
- Remove any build up of paint / plaster etc. especially around frame pivots and connections.
- All couplers and fittings used (for ties etc.) must be compatible with 50.8 mm O/D tube.
- Use correct lifting techniques when loading / unloading Zippy-Scaff Folding Scaffold; bend knees, not your back.
- Do not exceed the rated Working Load of the scaffold (225kg).
- Remember to think first and if in doubt, ask your supplier.